

OLYMPIC[®] Premium Interior Latex Eggshell

GENERAL DESCRIPTION

OLYMPIC® Premium Interior Latex Eggshell is recommended for use on properly prepared interior walls, ceilings, and interior trim.

RECOMMENDED SUBSTRATES

Concrete/Masonry Block Ferrous Metal Gypsum Wallboard-Drywall Plaster Wood

CONFORMANCE STANDARDS

AIM	Architectural Industrial Maintenance
CARB	California Air Resources Board
LADCO	Lake Michigan Air Directors Consortium
OTC	Ozone Transport Commission
SCQAMD	South Coast Air Quality Management District

DIRECTIONS FOR USE

Stir thoroughly before and occasionally during use. When using more than one can of the same color, intermix to ensure color uniformity.

Permissible temperatures during application:

Material:	50 to 90°F	10 to 32°C
Ambient:	50 to 90°F	10 to 32°C
Substrate:	50 to 90°F	10 to 32°C

APPLICATION INFORMATION

Application Method: Apply with a high quality brush, roller, paint pad, or by spray equipment. Where necessary, apply a second coat. Allow each coat to dry before applying the next coat.

Application Equipment: For smooth surfaces, use a polyester nylon brush or 3/16" - 3/8" nap roller cover. For textured surfaces, use a nylon brush or roller designed for this purpose. If applied by spray, back-brushing or back-rolling is recommended. For airless spray application, use tip size 0.015" - 0.021" and pressure range of 1500 - 2000 psi.

Thinning: No thinning is usually required. If necessary, thin with up to 1/4 pint (118 mL) of water per U.S. gallon (3.78L) of paint.

PRODUCT INFORMATION

Refer to the appropriate color formula book, automatic tinting equipment, and or computer color matching system for color formulas and tinting instructions.

72401	Ultra White (Also Base 1)	
72402	White (Also Base 2)	
72403	Base 3*	
72405	Base 5*	
*Must be tinted before use.		

Some colors, drastic color changes, or porous substrates may require more than one coat to achieve a uniform finish.

PRODUCT DATA

PRODUCT TYPE: SHEEN: **VOLUME SOLIDS*:** WEIGHT SOLIDS*: VOC*: WEIGHT/GALLON*: *Product data calculated on 72401.

Vinyl Acetate Ethylene Latex Eggshell: 3 to 8 (60° Gloss Meter) 34% +/- 2% 50% +/- 2% 0 g/L (0 lbs./gal.) 11.2 lbs. (5.1 kg) +/- 0.2 lbs. (91 g)

COVERAGE: One gallon (3.78 Liters) covers approximately 400 sq. ft. (37.2 sq. meters) on primed, smooth non-porous surfaces.

(****=*********************************	
Wet Film Thickness:	4.0 mils
Wet Microns:	102
Dry Film Thickness:	1.4 mils
Dry Microns:	36
Coverage does not	include variation

ion due to application methods, surface porosity, and/or mixing.

DRYING TIME: Dry time @77°F (25°C); 50% relative humidity.

To Touch	1 hour
To Recoat:	4 hours
To Full Cure:	30 days

Drying times listed may vary depending on temperature, humidity, film build, color, and air movement.

WASHING INSTRUCTIONS: Wait at least 14 days after painting before cleaning the surface with a non-abrasive mild cleaner.

CLEAN UP: Wipe up spills immediately with a damp cloth or sponge. Wash brushes, rollers and other painting tools with soap and water immediately after use.

DISPOSAL: Contact your local environmental regulatory agency for guidance on disposal of unused product. Do not pour down a drain or storm sewer. Over 200°F (93°C)

FLASH POINT:

FEATURES / BENEFITS

Features

Zero VOC, low odor Environmentally preferred Excellent coverage & hide Durable and washable finish Good stain resistance Soap and water cleanup

Benefits

Paint as provided is free of volatile organic compounds Safer on the environment Hides surface imperfection Withstands repeated cleaning Resist minor spillage or soiling from common household stains Easy to clean up hands and tools

OLYMPIC[®] Premium Interior Latex Eggshell

GENERAL SURFACE PREPARATION

Surfaces to be coated must be dry, clean, sound, and free from all contamination including loose and peeling paint, dirt, grease, oil, wax, concrete curing agents and bond breakers, chalk, efflorescence, mildew, rust, product fines, and dust. Remove loose paint, chalk, and efflorescence by wire brushing, scraping, sanding, and/or pressure washing. Putty all nail holes and caulk all cracks and open seams. Sand all glossy, rough, and patched surfaces. Feather back all rough edges to sound surface by sanding. Prime all bare and porous substrates with an appropriate high quality latex primer. WARNING! If you scrape, sand, or remove old paint, you may release lead dust or fumes. LEAD IS TOXIC. EXPOSURE TO LEAD DUST OR FUMES CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a properly fitted NIOSH-approved respirator and prevent skin contact to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the USEPA National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead. In Canada, contact a regional Health Canada office. Follow these instructions to control exposure to other hazardous substances that may be released during surface preparation.

CONCRETE/MASONRY BLOCK: Mortar should cure for at least 30 days and preferably 90 days prior to priming. Fill block with an appropriate block filler. Surfaces previously coated with water thinned cement-based paint must be prepared with extra care. If the material appears to be adhering tightly, a masonry sealer may be applied to seal the surface. Check adhesion by applying a piece of masking tape. If the sealer peels off and has loose particles, remove all chalking or crumbling material, re-seal and re-check adhesion.

FERROUS METAL: The surface must be cleaned thoroughly to remove any dust, rust, and surface contaminants, and then primed with a high quality latex primer.

GYPSUM WALLBOARD-DRYWALL: Nails or screws should be countersunk, and they along with any indentations should be mudded flush with the surface, sanded smooth and cleaned to remove any dust, then prime with a high quality latex primer prior to painting the substrate.

PLASTER: Plaster, hardcoat, skim coat, or other alkaline surfaces should be allowed to cure for at least 30 days prior to priming with a high quality latex alkali resistant primer.

WOOD: Unpainted wood or wood in poor condition should be sanded smooth, wiped clean, then primed. Any knots or resinous areas must be primed before painting. Countersink all nails, putty flush with surface, then prime with a high quality latex primer.

LIMITATIONS OF USE

FOR INTERIOR USE ONLY. Apply when air, product, and surface temperatures are between 50°F (10°C) and 90°F (32°C). Not recommended for use on floors or in high humidity areas. PROTECT FROM FREEZING.

PACKAGING

Quart (946 mL) 1-Gallon (3.78 L) 5-Gallon (18.9L)

Not all products available in all sizes.

SAFETY PRECAUTIONS

Before using the products listed in this publication, carefully read each product label and follow directions for its use. Please read and observe all the warnings and precautionary information on the product labels. Material Safety Data Sheets are available through our Sales Representative, Retailer or by calling (412) 492-5555.

Spray equipment must be handled with due care and in accordance with manufacturer's recommendations. High pressure injection of coatings into the skin by airless equipment may cause serious injury.

USE WITH ADEQUATE VENTILATION. KEEP OUT OF REACH OF CHILDREN.

PPG Architectural Finishes, Inc. believes the technical data presented is currently accurate: however, no guarantee of accuracy, comprehensiveness, or performance is given or implied. Improvements in coatings technology may cause future technical data to vary from what is in this bulletin. For complete, up-to-date technical information, call 1-800-426-6306.



Olympic® - US PPG Industries, Inc. Architectural Coatings One PPG Place Pittsburgh, PA 15272 www.olympic.com

Technical Services 1-800-426-6306

Architect/Specifier 1-888-PPG-IDEA Olympic - Canada PPG Canada, Inc. Architectural Coatings 4 Kenview Blvd Brampton, ON L6T 5E4 T.D. 3529 4/2009 (Supersedes 11/2008)