


# TENDER FOR TYPICAL 2-10-4 STEAM LOCOMOTIVE WITH ODYSSEY AND RAILSOUNDS PICTORIAL WIRING DIAGRAM



NOTE: Physical position of components may vary by tender type.

NOTE: This Black wire connects to the underside of the circuit board.

NOTE: Colors of wires may vary. You must trace all wires to verify connections.

Power Supply

Wireless Tether to Engine

AD20 Board



Ground Strap

Ground Strap

Center Rail Pick-up

Nine Volt Battery Clip

Ground Strap

Ground Strap

Center Rail Pick-up

Coil Coupler

Speaker

Speaker

Rail Sound ← Signal Sound  
Sound Switch

Bulb for Brakemans Doghouse Class Only

Marker Lamp LED

Marker Lamp LED

Rear Tender Lamp

RailSounds Board

Mother Board

White Connector Plug