




QUICK START (Continued)

Address Your Engine


First, you must address the engine. This “tells” your CAB-2 which locomotive you want to control. This is important when you have more than one engine on your layout.

NOTE: CAB-2 will revert to CAB-1 mode for any engine, train or accessory UNLESS you enter the options for that addressed unit either manually or with a memory module. (See page 46 or page 74 respectively)


To address an engine with an ID# of 1:



1. Press ENG



2. Press 1



3. Press Start Up

Start 'Er Up

Now it is time to start up your engine’s sound system.

To start the engine’s RailSounds system, Tap Start-Up on the Touch-Screen or any action key (Whistle, Bell, Velocity Throttle, etc.)

Your engine sound system will start up and the Touch-Screen Control Panel will appear.

NOTE: Press and Hold Start-Up and you will hear Tower-Comm or Crew-Talk before engine start.

NOTE: Refer to your Engine Manual or page 54 for the procedure to CHANGE THE ENGINE ID.