

ACRONYM	LCD DISPLAY	MORE LIST TEXT	FUNCTION NAME
DCH	CHRONOMETER = (VALUE)	DIS CHRONO	Display Chronometer
DOD	ODOMETER = (VALUE)	DIS ODOMETER	Display Odometer
DTO	TRIP OD = (VALUE)	DIS TRIP OD	Display Trip Odometer
DTV	TRACK VOLTAGE = (VALUE)	DIS TR VOLTAGE	Display Track Voltage
FBR	BRAKE SOUNDS ON/OFF	FUNC BRAKE I/O	Brake Sounds on/off
FCC	CLICK CLACK ON/OFF	FUNC CL CL I/O	Clickety-Clack on/off
FCH	CAB CHATTER ON/OFF	FUNC CHAT I/O	Cab Chatter
FCM	CONV MODE ON/OFF	FUNC CONV MODE	Conventional Mode
FDL	DIR LOCK ON/OFF	FUNC DIR LOCK	Direction Lock on/off
FFR	LOCOMOTIVE RESET	FUNC ENG RESET	Resets Locomotive To Factory Defaults
FMR	(MEASURE ROUTE MENU)	FUNC MEAS RTE	Measure Route
FRM	MAINTENANCE RESET	FUNC RES MAINT	Reset Maintenance
FSC	SPEED CONTROL ON/OFF	FUNC SPEED CONTROL	Speed Control Mode
FTS	TRACK SIGNAL	FUNC TR SIGNAL	Track Signal Feedback
LA1	AUX LIGHT 1 ON/OFF	LT AUX 1	Aux1 on Interior
LA2	AUX LIGHT 2 ON/OFF	LT AUX 2	Aux2 on Mars
LA3	AUX LIGHT 3 ON/OFF	LT AUX 3	Aux3 on Ditch
LBE	BEACON LIGHT ON/OFF	BEACON	Beacon on/off
LDI	DITCH LIGHT ON/OFF	DITCH	Ditch on/off
LFB	FIREBOX GLOW ON/OFF	FIREBOX	Firebox only on Interior
LFB	FIREBOX GLOW ON/OFF	FIREBOX	Firebox only on Mars
LFB	FIREBOX GLOW ON/OFF	FIREBOX	Firebox only on Ditch
LHD	HEADLIGHT ON/OFF	LT HEADLIGHT	Headlight on Interior
LIN	INTERIOR LIGHT ON/OFF	LT INTERIOR	Interior on/off
LIN	INTERIOR LIGHT ON/OFF	LT INTERIOR	Interior on Mars
LIN	INTERIOR LIGHT ON/OFF	LT INTERIOR	Interior on Ditch
LMA	MARS LIGHT ON/OFF	MARS	Mars on/off
LMK	MARKER LIGHT ON/OFF	MARKER	Marker LED
LMK	MARKER LIGHT ON/OFF	MARKER	Marker Light on Interior
LMK	MARKER LIGHT ON/OFF	MARKER	Marker Light on Ditch
LMK	MARKER LIGHT ON/OFF	MARKER	Marker Light on Mars
LNB	NUMBER BD ON/OFF	NUMBER BD	Number Board on Mars
LNB	NUMBER BD ON/OFF	NUMBER BD	Number Boards on Ditch
LNB	NUMBER BD ON/OFF	NUMBER BD	Number Boards on Mars and Ditch
LRL	RUNNING LIGHT ON/OFF	RUNNING	Running Lights on Mars and Ditch
LTI	INSP LIGHT ON/OFF	TRACK INSP	Track Inspection Lights on Ditch
MDL	(DITCH LIGHT MENU)	DITCH LT	Ditch Light Menu
MDS	(DOPPLER MENU)	DOPPLER MENU	Doppler Loop Menu
MLU	(LASH UP MENU)	LASH UP	Lash Up Menu
MMS	(MAX SPEED MENU)	MAX SPEED	Max Speed Set
MPG	PS1 PROGRAM MODE	MENU PROGMODE	Access To Ps1 Programming Options
MTV	MIN/MAX TRACK VOLTAGE	MENU TR VOLTS	Sets Min & Max Variable Channel Voltage
PS1	PROTOSOUND 1	NO DISPLAYED MESSAGE	PS1 engine start up
S01	CUSTOM SOUND 1	CUSTOM 1	Custom Sound 1
S02	CUSTOM SOUND 2	CUSTOM 2	Custom Sound 2
S03	CUSTOM SOUND 3	CUSTOM 3	Custom Sound 3
S04	CUSTOM SOUND 4	CUSTOM 4	Custom Sound 4
S05	CUSTOM SOUND 5	CUSTOM 5	Custom Sound 5
S06	CUSTOM SOUND 6	CUSTOM 6	Custom Sound 6
S07	CUSTOM SOUND 7	CUSTOM 7	Custom Sound 7
S08	CUSTOM SOUND 8	CUSTOM 8	Custom Sound 8
S09	CUSTOM SOUND 9	CUSTOM 9	Custom Sound 9
S10	CUSTOM SOUND 10	CUSTOM 10	Custom Sound 10
SCC	CPLR CLOSE SOUND	CPLR CLOSE	Coupler Close
SCS	CPLR SLACK SOUND	CPLR SLACK	Coupler Slack
SFS	FWD SIGNAL SOUND	FWD SIG	Fwd Horn Signal
SI1	IDLE SND SEQUENCE 1	SND IDLE SEQ 1	Maintenance Recipe 1
SI2	IDLE SND SEQUENCE 2	SND IDLE SEQ 2	Maintenance Recipe 2
SI3	IDLE SND SEQUENCE 3	SND IDLE SEQ 3	Maintenance Recipe 3
SI4	IDLE SND SEQUENCE 4	SND IDLE SEQ 4	Maintenance Recipe 4
SI5	IDLE SND SEQUENCE 5	SND IDLE SEQ 5	Maintenance Recipe 5
SI6	IDLE SND SEQUENCE 6	SND IDLE SEQ 6	Maintenance Recipe 6
SI7	IDLE SND SEQUENCE 7	SND IDLE SEQ 7	Maintenance Recipe 7
SI8	IDLE SND SEQUENCE 8	SND IDLE SEQ 8	Maintenance Recipe 8
SRS	REV SIGNAL SOUND	REV SIG	Rev Horn Signal
SSD	EXT SHUT DWN SOUND	SND EXT SD	Extended Shut Down
SSU	EXT START UP SOUND	SND EXT SU	Extended Start Up
STW	TRAIN WRECK SOUND	TR WRECK	Train Wreck
TCV	TRACK VOLTAGE OFF	TR VOLTS OFF	Sets Variable Track Voltage To 0
TZV	TRACK VOLTAGE MIN	TRACK VOLT MIN	Sets Variable Track Voltage To minimum